




## Installation & Maintenance Manual

**MOL 1650-3H (B70 2-3)**

**Oil Burner**

11/12

## DESCRIPTION





### COMPONENTS

1. Flame cone
2. Shrouded disc
3. Nozzle
4. Nozzle assembly
5. Ignition electrodes
6. Ignition cable
7. Ignition transformer
8. Photoresistor
9. Control box
10. Front plate, relay base
11. Switch I-II
12. Indicating lamp Stage 2
13. Cover, inspection glass
14. Indicating lamp Stage 1
15. Switch 0-I
16. Electric panel
17. Contactor
18. Thermal overload protection
19. Motor
20. Locking device, flange
21. Solenoid valves
22. Connecting pipe
23. Pump-solenoid valve bloc
24. Air intake
25. Solenoid valve bloc
26. Nozzle assembly adjustment
27. Scale, air regulation
28. Connecting pipe, solenoid valve bloc-adjustment device
29. Air damper
30. Pump
31. Adjustment device

# TECHNICAL DATA

## DIMENSIONS



	Length of burner tube	Flange Measure B
Burner head Standard	364	324
Burner head Long design	664	624

## OUTPUT RANGE AND NOZZLES RECOMMENDED

	Oil capacity kg/h	Output kW	Output Mcal/h	Recommended nozzle Angle	Danfoss	Monarch	Recommended Pump pressure
Burner head	41-139	486-1648	418-1417	45° - 60°	B	PLP	14 bar

The net calorific value of 11,86 kWh/kg for light oil has been used.



## RECOMMENDED NOZZLE

Because of different boiler types existing on the market, with varying combustion chamber designs, it is not possible to

state a definite spray angle or spray pattern.


Note that the spray angle and the spray pattern change with the pump pressure.

## BURNERHEAD



# TECHNICAL DATA

## DIMENSIONS OF FLANGE



# GENERAL INSTRUCTIONS

## GENERAL RULES

The installation of an oil burner should be carried out in accordance with local regulations. The installer of the burner must therefore be aware of all regulations relating to oil and combustion.

Only oil suitable for the burner should be used and then in combination with a suitable oil filter before the oil pump of the burner.

If the burner is replacing an existing burner make sure that the oil filter is replaced or cleaned. The installation must only be undertaken by experienced personnel. Care should be taken by the installer to ensure that no electrical cables or fuel/gas pipes are trapped or damaged during installation or service/maintenance.

## INSTALLATION INSTRUCTIONS

General installation instructions accompany the burner and should be left in a prominent place adjacent to the burner.

## ADJUSTMENT OF BURNER

The burner is from the factory pre-set to an average value that must then be adjusted to the boiler in question.

All burner adjustments must be made in accordance with boiler manufacturers instructions. These must include the checking of flue gas temperatures, average water temperature and CO<sub>2</sub> or O<sub>2</sub> concentration.

To adjust the combustion device, start by increasing the air volume and the nozzle assembly somewhat. When the burner starts it is burning with excess air and smoke number 0. Reduce the nozzle assembly adjustment until soot occurs, and then increase the adjustment to make the soot disappear again. Then the volume of air is reduced until soot occurs and increased again to reach a combustion free of soot.

By this procedure an optimum adjustment is obtained. If larger nozzles are used the preadjustment of both the air volume and the nozzle assembly must be increased.

A whistling sound may be heard which can be eliminated or reduced as follows: Increase the nozzle assembly adjustment somewhat. The CO<sub>2</sub>-content and consequently the air volume will then be reduced.

## CONDENSATION IN CHIMNEY

A modern burner works with less excess air and often also with smaller nozzles than older models. This increases the efficiency but also the risk of condensation in the chimney. The risk increases if the area of the chimney flue is too large. The temperature of the flue gases should exceed 60°C measured 0,5 metres from the chimney top.

Measures to raise the temperature:  
Insulate the chimney in cold attics  
Install a tube in the chimney  
Install a draught regulator (dilutes the flue gases during operation and dries them up during standstill)  
Increase the oil quantity  
Raise the flue gas temperature by removing turbulators, if any, in the boiler.

## OIL SUPPLY

The oil line should be dimensioned in accordance with the pump manufacturer's instruction. In the suction line to the burner a filter should be mounted to prevent any particles in the oil from reaching the burner. If the installation consists of several burners each one should have its own suction line from the tank or a circulation system should be used.

The temperature in the oil line should be kept as constant as possible. Avoid exposing the line to excessive cold which may cause blockages of paraffin deposits.

The oil pipe and electric cable should be fitted so that the burner can be placed on the floor for inspection of the combustion device.

## PUMP ADJUSTMENT

See separate description.


## MAINTENANCE

The boiler/burner should be examined regularly for any signs of malfunction or oil leakage.

# GENERAL INSTRUCTIONS

## ADJUSTMENT OF NOZZLE ASSEMBLY

Adjust the nozzle assembly with the adjustment screw D to the desired position.



## AIR ADJUSTMENT


### First stage:

Set the operating switch (S2) on low capacity (I). Loosen the screw (A) and turn the damper to the position wanted. Tighten the screw (A) again.

### Second stage:

Set the operating switch (S2) on high capacity (II). Screw the knurled ring (B) in (reduce) or out (increase). The position of the damper can be read on the damper scale (C).


Check the air adjustment by making a flue gas analysis.



# MAINTENANCE OF OIL BURNER

**Warning:** Before doing any service switch off power at the main switch and cut off the oil supply.

## SERVICE OF BURNER HEAD




### NOTE!

For maintenance of the brake plate, nozzles, electrodes etc, when using a long design of the burner tube, you have to **remove the nozzle assembly from the connecting pipe and move the assembly backwards** in the fan housing (from the boiler).

# ELECTRIC EQUIPMENT

## OIL BURNER CONTROL: LMO24.255.B2B/LOA44

### WIRING DIAGRAM



### LIST OF COMPONENTS

A1	Oil burner control
B1	Photoresistor
F1	Operating fuse
F2	Fuse
F3	Fuse
H1	Lamp, low capacity
H2	Lamp, high capacity
K1	Thermal overload protection
M1	Burner motor
S1	Operating switch
S2	Operating switch, high/low capacity
S3	Control thermostat
S4	Temperature limiter
S5	Micro switch for hinged door
S6	Control thermostat, high/low capacity
S7	Main switch
S20	Main switch
T1	Ignition transformer
X1	Connection terminal board
X2	Earth terminal
X3	Plug-in contact "Euro", burner
X4	Plug-in contact "Euro", boiler
X5	Plug-in contact "Euro", high/low burner
X6	Plug-in contact "Euro", high/low boiler
X7	Plug-in contact "Euro" 3-phase, burner
X8	Plug-in contact "Euro", 3-phase, boiler
Y0	Solenoid valve start
Y1	Solenoid valve 1
Y2	Solenoid valve 2

If S6 is missing connection between T6 and T8.

Mains connection and fuse in accordance with local regulations.

# ELECTRIC EQUIPMENT

## OIL BURNER CONTROL: LMO24.255.B2B

### FUNCTION

1. Switch on operating switch and twin thermostat  
The burner motor starts, an ignition spark is formed, the prepurge goes on till the prepurge period expires and the solenoid valve 1 opens (2).
2. Solenoid valve 1 opens  
Oil mist is formed and ignited. The photocell indicates a flame.
3. The safety time expires
  - a. If no flame is established before this time limit the control cuts out.
  - b. If for some reasons the flame disappears after this time limit, the burner will make an attempt to re-start.
4. Full load thermostat ON  
The burner is in operating position and can now change between high and low capacity.
- 4-5. Operating position  
If the burner operation is interrupted by means of the main switch or the thermostat, a new start takes place when the conditions in accordance with point 1 are fulfilled.

The oil burner control cuts out

A red lamp in the control is lit. Press the reset button and the burner re-starts.

### TECHNICAL DATA

Pre-ignition time:	25 s
Pre-purge time:	25 s
Post-ignition time:	5 s
Safety lock-out time:	5 s
Reaction time on flame failure:	max. 1 s
Ambient temperature:	from - 20 to +60°C
Min. current with flame established:	30 µ A
Max. photo current at start:	5,5 µ A
Enclosure:	IP 40

### CONTROL OF PHOTO CURRENT

Current through photo unit is measured with a d.c. ammeter (a moving coil instrument connected in series with the photo unit).

# INSTRUCTIONS PUMP TYPE DANFOSS RSA 125

## TECHNICAL DATA

Viscosity range: 1,3-18,0 mm<sup>2</sup>/s  
 Pressure range: 12,0-21,0 bar  
 Oil temperature: -10 to +70°C



## COMPONENTS

1. Pressure gauge port G 1/8"
2. Nozzle port G 1/8"
3. Suction line G 1/4"
4. Suction line G 1/4"
5. Return line G 1/4"
6. Return line R 1/4"
7. By-pass plug
8. Pressure adjustment,  
5 mm allen key

## SUCTION LINE TABLES

The suction line tables consist of theoretically calculated values where the pipe dimensions and oil velocity have been matched so that turbulences will not occur. Such turbulences will result in increased pressure losses and in acoustic noise in the pipe system. In addition to drawn copper piping a pipe system usually comprises 4 elbows, a non-return valve, a cut-off valve and an external oil filter.





The sum of these individual resistances is so insignificant that they can be disregarded. The tables do not include any lengths exceeding 100 m as experience shows that longer lengths are not needed.

The tables apply to a standard fuel oil of normal commercial quality according to current standards. On commissioning with an empty tube system the oil pump should not be run without oil for more than 5 min. (a condition is that the pump is being lubricated during operation).

The tables state the total suction line length in metres at a viscosity of 6,0 mm<sup>2</sup>/s.

## PURGING

On 1-pipe systems it is necessary to purge the pump. On 2-pipe systems purging is automatic through the return line.

									
<b>1-pipe system</b>									
Height H	Pipe diameter ø10mm								
m	m								
With an overlying tank a 1-pipe-system is not recommended									
									
<b>Two-pipe system</b>									
Height H	Pipe diameter ø12mm								
m	m								
With an underlying tank a 1-pipe-system is not recommended									
Height H	Pipe diameter ø15mm								
m	m								
Two-pipe system									
Height H	Pipe diameter ø20mm								
m	m								
4,0	39	81	100	100	0	20	41	100	100
3,5	36	76	100	100	-0,5	18	36	89	100
3,0	34	71	100	100	-1,0	15	31	77	100
2,5	32	66	100	100	-1,5	13	26	65	100
2,0	29	61	100	100	-2,0	10	22	53	100
1,5	27	56	100	100	-2,5	8	17	41	100
1,0	25	51	100	100	-3,0	6	12	29	91
0,5	22	46	100	100	-3,5	3	7	17	53
					-4,0	1	2	5	15

## FUNCTION DANFOSS

### RSA 95 - 125


When the pump is started oil is drawn through the suction port "S" via filter "H" to the suction side of the gearwheel set "C". From here the gearwheel set pumps the oil to the pressure side and at the same time the oil becomes pressurized. The oil is led to cut-off and regulating valve "V" which opens when the set pressure is reached.

The pressure is controlled and kept constant by regulating valve "V". At the same time the gearwheel set "C" distributes the oil through nozzle port "P" and pump return side "R" via the shaft seal "F".

The quantity of oil supplied to nozzle port "P" is determined by the pressure set on regulating valve "V" and the nozzle/resistance in the nozzle line.

In 2-pipe-systems excess oil is led back to the oil tank. In 1-pipe-systems the by-pass plug "A" must be removed to give free flow back to the suction side via return line "G" with return port "R" closed.

When the pump is stopped, the pump



output drops and produces a drop in the oil pressure. The spring in the regulating valve presses the regulating piston forward until it seals in port "P". This cuts off the oil flow to the nozzle and ensures that the nozzle line is effectively shut off.

If the pump is overloaded, i.e. more oil is demanded than the gearwheel is able to pump under the given conditions, the oil pressure falls below

the set value because the piston of the regulating valve moves towards its closed position and partially or wholly cuts off the return oil via port "O".


This can be remedied by

- reducing the pump pressure
- reducing the capacity, i.e. smaller nozzle or greater resistance
- changing to a pump with higher capacity


## MOUNTING/DISMOUNTING BY-PASS PLUG

In a 2-pipe-system excess oil is led back direct to the oil tank. In a 1-pipe-system the by-pass plug must be removed so that there is a free passage back to the suction side through the return line with the return port closed.

One pipe system




Two pipe system



## EXCHANGE OF FILTER



## FUNCTION FOR DANFOSS RSA



1. Nozzle 1
2. Nozzle 2
3. Nozzle 3
4. Solenoid valve Nozzle 1
5. Solenoid valve Nozzle 2
6. Solenoid valve Nozzle 3  
and adjustment of air Stage 2
7. Oil pump
8. Air adjustment Stage 2

N.B. Nozzle 1+2= 1<sup>st</sup> Stage  
Nozzle 1+2+3= 2<sup>nd</sup> Stage

## NOZZLE TABLE

Pump pressure bar

Goh	10	11	12	13	14	15	16	17										
	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h	kg/h	kW	Mcal/h
1,00	3,72	44	38	3,90	46	40	4,08	48	42	4,24	50	43	4,40	52	45	4,56	54	46
1,10	4,09	48	42	4,29	51	44	4,48	53	46	4,67	55	48	4,84	57	49	5,01	59	51
1,20	4,47	53	46	4,68	55	48	4,89	58	50	5,09	60	52	5,29	63	54	5,47	65	56
1,25	4,65	55	47	4,88	58	50	5,10	60	52	5,30	63	54	5,51	65	56	5,70	68	58
1,35	5,02	59	51	5,27	62	54	5,50	65	56	5,73	68	58	5,95	70	61	6,15	73	63
1,50	5,58	66	57	5,85	69	60	6,11	72	62	6,36	75	65	6,60	78	67	6,83	81	70
1,65	6,14	73	63	6,44	76	66	6,73	80	69	7,00	83	71	7,27	86	74	7,52	89	77
1,75	6,51	77	66	6,83	81	70	7,14	85	73	7,42	88	76	7,71	91	79	7,97	95	81
2,00	7,45	88	76	7,81	93	80	8,16	97	83	8,49	101	87	8,81	104	90	9,12	108	93
2,25	8,38	99	85	8,78	104	90	9,18	109	94	9,55	113	97	9,91	118	101	10,26	122	105
2,50	9,31	110	95	9,76	116	100	10,19	121	104	10,61	126	108	11,01	131	112	11,39	135	116
2,75	10,24	121	104	10,73	127	109	11,21	133	114	11,67	138	119	12,11	144	123	12,53	149	128
3,00	11,16	132	114	11,71	139	119	12,23	145	125	12,73	151	130	13,21	157	135	13,67	162	139
3,50	13,03	154	133	13,66	162	139	14,27	169	146	14,85	176	151	15,42	183	157	15,95	189	163
4,00	14,89	176	152	15,62	185	159	16,31	193	166	16,97	201	173	17,62	209	180	18,23	216	186
4,50	16,75	199	171	17,57	208	179	18,35	218	187	19,10	226	195	19,82	235	202	20,51	243	209
5,00	18,62	220	190	19,52	231	199	20,39	242	208	21,22	252	216	22,03	261	225	22,79	270	232
5,50	20,48	243	209	21,47	255	219	22,43	266	229	23,34	277	238	24,23	287	247	25,07	297	256
6,00	22,34	265	228	23,42	278	239	24,47	290	250	25,46	302	260	26,43	313	270	27,49	326	280
6,50	24,20	287	247	25,37	301	259	26,51	314	270	27,58	327	281	28,63	340	292	29,63	351	302
7,00	26,06	309	266	27,33	324	279	28,55	339	291	29,70	352	303	30,84	366	314	31,91	378	325
7,50	27,92	331	285	29,28	347	299	30,59	363	312	31,83	377	325	32,04	392	337	34,19	405	349
8,00	29,79	353	304	31,23	370	318	32,63	387	333	33,95	403	346	35,25	418	359	36,47	433	372
8,50	31,65	375	323	33,18	393	338	34,66	411	353	36,07	428	368	37,45	444	382	38,74	459	395
9,00	33,59	398	343	35,14	417	358	36,71	435	374	38,19	453	389	39,65	470	404	41,02	486	418
9,50	35,37	419	361	37,09	440	378	38,74	549	395	40,31	478	411	41,85	496	427	43,30	514	442
10,00	37,23	441	380	39,04	463	398	40,78	484	416	42,44	503	433	44,06	523	449	45,58	541	465
11,00	40,96	486	418	42,94	509	438	44,86	532	457	46,68	554	476	48,46	575	494	50,14	595	511
12,00	44,68	530	456	46,85	556	478	48,94	580	499	50,92	604	519	52,87	627	539	54,70	648	558
14,00	52,12	618	531	54,65	648	557	57,10	677	582	59,41	705	606	62,68	732	629	63,81	757	651
16,00	59,57	706	607	62,46	741	637	65,26	774	666	67,90	805	692	70,49	836	719	72,93	865	744
18,00	67,02	795	683	70,27	833	717	73,41	871	749	76,39	906	779	79,30	940	809	82,05	973	837
20,00	74,47	883	759	78,08	926	796	81,57	967	832	84,87	1007	865	88,11	1045	899	91,17	1081	930
22,00	81,91	971	835	85,89	1019	876	89,73	1064	915	93,36	1107	952	96,92	1149	988	100,28	1189	1023
24,00	89,36	1060	911	93,70	1111	956	97,88	1208	1039	103,36	1107	952	105,74	1254	1078	109,40	1297	1116
26,00	96,81	1148	987	101,50	1204	1035	106,04	1258	1081	110,33	1308	1125	114,55	1359	1168	118,52	1406	1209

The table applies to oil with a viscosity of 4,4 mm<sup>2</sup>/s (cSt) with density 830 kg/m<sup>3</sup>.

# FAULT LOCATION

## BURNER FAILS TO START

Situation	Possible causes	Remedies
Motor runs	Flame instability	
Burner pre-purges	Incorrect head settings Low oil pressure Excess air	Check nozzle to burner head dimension and electrode position Check oil pressure Adjust air damper
Flame occurs		
Burner locks out	Photocell not seeing light Photocell failed	Check that photocell is clean and unobstructed Confirm with new photocell
Motor runs	Control faulty	Confirm with new control. (NB. it is advisable to change the photocell if also changing control)
Burner pre-purges	False light	Check that photocell is not seeing ambient light
No flame occurs	No spark	Check that H.T. leads are sound and are not arcing other than at electrode gap
Burner locks out	No oil	Check oil supply to burner - check that pump is not airlocked Check operation of magnetic valve

## BURNER FAILS TO START AFTER NORMAL OPERATION

Burner fails to start	Fuse has blown	Check or replace fuse if necessary. Check reason for failure
	Appliance thermostat has not reset	Adjust thermostat
Lamp not lit	Appliance overheat device has operated	Reset overheat device. Find reason for its operation and rectify
	Control relay or photocell defective	Check by replacement
Motor runs	No oil being delivered	Check that tank, oil lines, fire valve, pump and nozzle are all in good order
Burner runs to lockout	Excessive flue draught is preventing flame establishment	Rectify condition
	No spark	Check ignition transformer. Check electrode gap and porcelains

## DELAYED IGNITION, BURNERS STARTS VIOLENTLY

Burner pulsates on start-up only with hot flue	Excessive draught	Recommission burner
Burner pulsates on start-up	Nozzle partly blocked	Replace nozzle
	Oil pressure too low	Check and recommission
	Flue blocked or damaged	Check and rectify
	Fan slipping on shaft	Check and retighten
	Pump coupling loose or worn	Check and replace
Burner starts violently	Delayed ignition	Check the electrode adjustment, see diagram Check electrodes for damage Check H.T. leads for damage and disconnection

Enertech Limited,  
P O Box 1,  
Vines Lane  
Droitwich,  
Worcestershire,  
WR9 8NA

Tel: +44 (0) 1905 794331    Fax: +44 (0) 1905 794017  
Email: [info@nu-way.co.uk](mailto:info@nu-way.co.uk)    Web: [www.nu-way.co.uk](http://www.nu-way.co.uk)

