


# SELECTOS Model D16 spare parts list

## Pressure Jet Range Oil Burners



The above for pictorial identification only

Part No.	Description	Burner Model			Part No.	Description	Burner Model		
		A	B	T			A	B	T
001048	Motor 3 Phase 250 Watt	*	*	*	499276	Air Flap Spindle	*	*	*
001097	Motor 1 Phase 250 Watt	*	*	*	511018	Gasket	*	*	*
040029	Transformer	*	*	*	511020	Gasket	*	*	*
050068	Twin Electrode	*	*	*	580001	Nozzle	*	*	*
070100	Control Box SAT TF 802B	*	*	*	585020	Pump V4	*	*	*
070112	Control Box SAT TF 801B	*	*	*	585054	Pump MSLAO 50	*	*	*
071020	Photocell	*	*	*	598061	Coupling Complete	*	*	*
301011	Housing Assembly	*	*	*	601045	Inner Oil Line	*	*	*
310016	Motor Plate	*	*	*	601046	External Oil Line FCAD	*	*	*
310042	Adaptor Plate	*	*	*	601054	External Oil Line STD	*	*	*
321032	Air Flap	*	*	*	601056	External Oil Line FCAD	*	*	*
425016	Fan	*	*	*	601057	External Oil Line STD	*	*	*
440033	Control Box Bracket	*	*	*	621330	Inner Oil Line	*	*	*
462041	Knurled Nut	*	*	*	651033	Ignition Lead	*	*	*
470381	Flame Disc 94 mm	*	*	*	691121	Housing Cover	*	*	*
470386	Draught Tube	*	*	*	691170	Cylinder Assembly	*	*	*
470560.01	Flame Disc 90 mm	*	*	*					

When ordering spare parts please quote our part number and burner serial number if applicable

British Gas & Oil Burners Limited Telex: 81579 Cables: Selectburna Thet  
 Head Office & East Anglian Division Burrell Way Thetford Norfolk IP24 3RA Tel 0842 4444  
 London Division 117 Queenstown Road Battersea London SW8 3KH Tel 01-720 7011  
 Midland Division Cross Street Bridgtown Cannock Staffs WS11 3BZ Tel 054 35 71621  
 Northern Division Douglas Street, Hyde, Cheshire SK14 1RL Tel 061-351 1258  
 Scottish Division 38 Telford Road, East Lenziemill, Cumbernauld Tel 023 67 37471

