


SELECTOS Model SG16 spare parts list

Automatic Gas Burner



The above for pictorial identification only

Part No.	Description	Burner Model				Part No.	Description	Burner Model			
		A	B	C _B	C			A	B	C _B	C
001048	Motor 3 Phase 250 Watt	*	*	*	*	462041	Knurled Nut	*	*	*	*
001097	Motor 1 Phase 250 Watt	*	*	*	*	464110	Elbow	*			
002014	Air Flap Motor	*	*	*	*	470401	Draught Tube	*			
020066	Pressure Switch GW 3	*	*	*	*	499157.01	Manifold	*			
020067	Pressure Switch GW 10	*	*	*	*	499158.01	Hinge Plate	*			
040029	Transformer	*	*	*	*	499163.01	Manifold			*	*
050015	Electrode	*				499246	Hinge Pin	*			
050063	Twin Electrode		*	*	*	499276	Air Flap Spindle	*	*	*	*
050064	Probe	*				511009	Gasket	*			
050067	Twin Electrode/Probe Assembly	*				511018	Gasket	*			
070065	Control Box SAT TMG 740	*	*	*	*	511019	Gasket	*			
070087	Control Box L & G LFLI 335	*	*	*	*	511020	Gasket	*			
070106	Control Box SAT MMI 810	*	*	*	*	595017	Air Pressure Pipe	*	*	*	*
071017	UV Cell L & Gyr	*				610019	Inner Gas Line Tube	*	*	*	*
071025	UV Cell Satronic	*				470436	Combustion Head Assembly			*	*
301011	Housing Assembly	*	*	*	*	621034	Draught Tube	*			
310016	Motor Plate	*	*	*	*	621209	Combustion Head Assembly	*			
310039	Hinge Plate	*			*	621233	Draught Tube				*
310048	Hinge Plate	*			*	621271	Combustion Head Assembly	*			
321032	Air Flap	*	*	*	*	621313	Draught Tube	*			*
399046	Elbow	*			*	651032	Probe Lead Assembly	*	*	*	*
399051	Elbow	*			*	651035	Ignition Lead Assembly	*	*	*	*
425016	Fan	*	*	*	*	691051	Electrical Adaptor Box	*	*	*	*
440117	Gas Line Support Bracket	*	*	*	*	691106	Hinge Pins	*	*	*	*
440162	Air Flap Motor Bracket	*	*	*	*	691121	Housing Cover	*	*	*	*
440170	Pressure Switch Bracket	*	*	*	*	904062	Gas Nozzle and Restriction Ring	*			

When ordering spare parts please quote our part number and burner serial number if applicable

British Gas & Oil Burners Limited Telex: 81579 Cables: Selectburna Thet
Head Office & East Anglian Division Burrell Way Thetford Norfolk IP24 3RA Tel 0842 4444
London Division 117 Queenstown Road Battersea London SW8 3KH Tel 01-720 7011
Midland Division Cross Street Bridgtown Cannock Staffs WS11 3BZ Tel 054 35 71621
Northern Division Douglas Street, Hyde, Cheshire SK14 1RL Tel 061-351 1258
Scottish Division 38 Telford Road, East Lenziemill, Cumbernauld Tel 023 67 37471

