


B 65 T3S	MOL 1175 T3L 2H	Control Box	LMO24.255.B2B	92024201
B60-2H		Diffuser	120 Dia	11284115
(Bentone)		Ignition Electrodes	Pair	91924601
		Solenoid valve		91994701
		Fuel Pump	RSA 125	11019719
		Pump coupling		11811503
		Photocell	QRB	91240908
		Motor	1.5kW-3Phase	12031603
		Contactactor	CI9	11311001
		Transformer	EBI	11597701
		Mounting gasket		11278803 ?
		HT Leads	Pair required-500Lg	11933706
		Flexible oil line	1/4x3/8x1500mm Lg	11354208
		Fan Impellor	224x82	11824505
		Nozzle		
		Filters		
		Oil ram		91829904
B65-2	MOL 1175 T3L	Control Box	LMO24.255.B2B	92024201
(Bentone)		Diffuser	120 Dia	11284115
		Ignition Electrodes	Pair	91924601
		Solenoid valve		91994701
		Fuel Pump	RSA 125	11019719
		Pump coupling		11811503
		Photocell	QRB	91240908
		Motor	1.5kW-3Phase	12031603
		Contactactor	CI9	11311001
		Transformer	EBI	11597701
		Mounting gasket		11278803 ?
		HT Leads	Pair required-500Lg	11933706
		Flexible oil line	1/4x3/8x1500mm Lg	11354208
		Fan Impellor	224x82	11824505
		Nozzle		
		Filters		
		Damper Motor	SQN75.244.A21B	11942304
B65-3R	MOL 1175 T3L 3R	Control Box	LAL1.25E	91493901
(Bentone)		Diffuser	3 Nozzle-120 Dia	11284119
		Ignition Electrodes	Pair	91924701
		Solenoid valve		91994702
		Fuel Pump	RSA 125	11019719
		Pump coupling		11811503
		Photocell	QRB	91240908
		Motor	1.5kW-3Phase	12031603
		Contactactor	CI9	11311001
		Transformer	EBI	11597701
		Mounting gasket		11278803 ?
		HT Leads	Pair required-500Lg	11933706
		Flexible oil line	1/4x3/8x1500mm Lg	11354208
		Fan Impellor	224x82	11824505
		Nozzle		
		Filter		
		Damper Motor	SQN75.436.A21B	11942301

# 11. SPARE PART LIST



# 11. SPARE PART LIST

1. Flame cone		10. Axle compl.		27. Pump	
304mm	119 728 0105	55-2, 65-2	918 298 02	RSA95	110 197 23
404mm	119 728 0205	55-3, 65-3	918 298 01	55	
504mm	119 728 0305			RSA125	110 197 19
55		11. Adjustment bar		65	
288mm	119 721 0105	55-3, 65-3	118 450 01		
388mm	119 721 0205	55-2, 65-2	118 290 01	28. Solenoid valve	919 946 01
488mm	119 721 0305			compl.	
65		12. Adjustment device		Coil	115 971 01
		55-R, 65-R	918 299 04		
2. Nozzle assembly		13. Gasket set		29. Solenoid valve	919 947 01
380mm	919 746 01	55-R, 65-R	118 322 02	bloc compl.	
480mm	919 746 02			55-2, 65-2	
580mm	919 746 03	14. Nozzle key	113 461 01		
55-2				30. Solenoid valve	919 947 02
380mm	919 749 01	15. O-ring, nozzle assembly		bloc compl.	
480mm	919 749 02	55-3, 65-3	113 168 02	55-3, 65-3	
580mm	919 749 03	16. Fixing flange			
65-2		compl.	118 490 02	31. Connecting pipe	118 237 01
368mm	919 750 01	Guide bars	118 093 02	pump-solenoid valve bloc	
468mm	919 750 02	Fixing flange	118 235 01	compl.	
568mm	919 750 03			55-2H, 65-2H	
55-3		17. Gasket	112 788 03		
368mm	919 751 01	18. Gasket	118 398 01	32. Connecting pipe	118 428 01
468mm	919 751 02	fan housing-flange		solenoid valve-	
568mm	919 751 03			adjustment device	
65-3		19. Motor		55-2H, 65-2H	
		0,75kW 3-phase	120 316 01		
3. Nozzle line		55		33. Nipple, connection	118 423 01
368mm	118 414 01	1,5kW 3-phase	120 316 03	solenoid valve bloc	
468mm	118 414 02	65			
568mm	118 414 04	20. Cable 700mm	119 449 03	34. Angle	118 404 01
55-3, 65-3				55-2, 65-2	
380mm	118 104 01	21. Fan wheel			
480mm	118 104 02	224x62x19	118 245 04	35. Copper gasket	110 212 16
580mm	118 104 04	55		10,2x15x1,5	
55-2, 65-2		224x82x19	118 245 05		
		65		36. Cable solenoid valve	
4. Brake plate		22. Drive coupling	118 115 03	Stage1, 3 700mm	115 975 03
55-2, Ø120mm	119 347 01	compl.		Stage2 900mm	115 975 06
55-3, Ø120mm	119 735 01	23. Coupling part,	04 390 448 66		
65-2, Ø120mm	112 841 15	pump		37. Hydraulic hose	118 293 01
65-3, Ø120mm	112 841 19	24. Coupling part,	118 065 01	55-2, 65-2	
		fan wheel			
5. Bracket	112 738 01	25. Flange,	119 737 0105	38. Hydraulic hose	116 168 01
		motor		65-2	
6. Bracket	111 552 01	26. Conical shield	117 935 01		
		plate		39. Filter set	117 833 01
7. Ignition electrode pair off				RSA 90, 125	
55-3, 65-3	919 247 01				
65-2	919 246 01			40. Control box	
55-2	919 245 01			LAL 1.25	914 939 01
				LOA44252A27	915 595 02
8. Adjustment plate compl.				LMO24.255.R2B	920 242 01
55-2H, 65-2H	118 229 01			55-2, 65-2	
9. Adjustment plate compl.					
55-R, 65-R	918 288 01				

# 11. SPARE PART LIST

41. Relay base LAL LOA/LMO 55-2, 65-2	114 942 00 915 596 00	53. Inspection glass	118 088 01
42. Flange, Photoresistor QRB1	112 405 01	54. Gasket	117 953 01
43. Photoresistor compl. QRB-A 700mm	912 409 08	55. Protective grating	118 319 01
44. Contactor CI9	113 110 01	56. Cover	118 238 0105
45. Thermal overload protection 2,7-4,2A 65 1,8-2,8A 55	113 111 03 113 111 06	57. Gasket	118 249 01
46. Switch H-I 0-I	120 149 01 120 149 02	58. Cover, inspection glass	118 242 0105
47. Time meter	117 678 01	59. Inspection cover	117 080 01
48. Plug-in contact compl. female 7-pole male 7-pole green male 4-pole female 4-pole 55-2, 65-2 stage 2 55-3, 65-3 stage 3 black male 4-pole female 4-pole 55-3, 65-3 stage 2 male 5-pole female 5-pole	115 586 03 115 585 00 119 197 01 119 198 01 119 103 01 119 104 01 119 199 01 119 200 01	60. Test nipple	118 053 01
49. Indicating lamp green	117 211 03	61. Slewing bracket compl.	119 470 01
50. Fuse holder compl. 55-3, 65-3 55-2, 65-2 Fuse 6,3A	118 118 03 118 118 04 113 322 01	62. Covering plate, servo motor adjustment device 55-2H, 65-2H	118 239 0105 118 401 0105
51. Plug-in contact compl. 7+4+5+4-pole 55-3, 65-3 4+7+5-pole 55-2, 65-2	119 486 10 119 486 01	63. End piece	118 103 01
52. Locking ring	118 018 01	64. Servo motor SQN75.294A21B 2-stage, LAL SQN75.436A21B 3-stage, LAL SQN75.244A21B 2-stage, LOA/LMO	119 423 03 119 423 01 119 423 04
		65. Air damper compl. 55-2H, 65-2H	918 240 01 918 241 01
		66. Adjustment device 55-2H, 65-2H Spring, compl. adjustment device 55-2H, 65-2H	917 565 03 133 799 01
		67. Transformer EBI Cabel	115 977 01 117 570 04
		68. Ignition cable 500mm	119 337 06
		69. Flexible pipe 1500mm	113 542 08
		70. Oil filter compl. ½" Filter	114 293 04 914 314 03