

SPARE PARTS LIST

BURNER SERIES: NIDFL35			Category (see Note below)	
ITEM	CODE NO	DESCRIPTION	A	B
	D15-002G	FAN IMPELLOR 381x51		*
	C55-063F	OVERLOAD 6-9.2 AMP	*	
	C50-054M	PRESSURE Switch GW3	*	
	E01-003Y	Solenoid Valve 122	*	
	E01-004Z	Solenoid Valve 121	*	
	E05-034J	Flexible oil pipe 36"		*
	A30-018V	DAMPER MOTOR SQM		*
	G03-017X	Flexible Coupling Rubber	*	
	E03-043Z	FILTER 1" BSP		*
	E05-010W	Flexible oil pipe 18"	*	
	G06-011U	Probe (GAS)	*	
	G06-003D	Electrodes (OIL)	*	
	G05-005E	O' Rings	*	
	M29-252C	Diffuser (GAS)	*	
	L04-122V	DIFFUSER (OIL)	*	
	M29-302F	NOZZLE (GAS)	*	
	E08-152G	SKP70 ACTUATOR		*
	E01-070E	Solenoid Valve 3/4" BSP	*	
	C50-048X	PRESSURE Switch GW10/50	*	
	E01-160D	Solenoid Valve MVD		*
	C21-137L	DK2F Control		*

N.B. 1. Code numbers and types of electrical items listed are based on standard electrical supplies of 220-240V, 1-phase, 50 Hz., or 415V, 3-phase, 50 Hz. only.
 2. When ordering spare parts it is essential to quote the serial and specification numbers shown on the burner or burners.
 3. Categories: A - Short-Term Spares. B - Long-Term Spares.

