

**SPARES AND COMPONENTS  
DIVISION**



**SPARE PARTS LIST**

NU-WAY LTD. P.O. Box 1, Vines Lane,  
Droitwich,  
Worcs., WR9 8NA, England  
Tel. 0905 794331 & 794242  
Fax. 0905 794017  
Telex 338551 Nuway G  
Registered in England No. 299044  
a subsidiary company of Wolseley plc.

BURNER  
MODEL **FOL/EOL 18-25-33**

Item	Code No.	Description	Category (see note)	Price
1A	N24-436C	DRAUGHT TUBE - F/EOL 18		
1B	N24-435B	DRAUGHT TUBE - F/EOL 25-33		
2	U90-056V	INNER ASSEMBLY (TO SPEC ADVISED)		
3A	N24-413D	DIFFUSER - F/EOL 18		
3B	N24-433H	DIFFUSER - F/EOL 25-33		
4	U90-360N	ELECTRODE - F/EOL 18-25-33		
5	B09-217M	HT LEADS		
6	U34-091A	BURNER CASING		
7	A02-025M	MOTOR 70 WO 220/240 <i>USE A02033M</i>		
8	D04-010Z	FAN IMPELLOR		
9	MISC	COUPLING (MOTOR)		
10A	E02-157X	FUEL PUMP AS47 B7538		
10B	E02-155V	FUEL PUMP BFPR3 071NO198		
11A	B16-030X	COIL FOR AS47		
11B	B16-056V	COIL FOR BFP PUMP		
12A	C21-208L	CONTROL BOX - DANFOSS BH061		
12B	C21-146V	CONTROLBOX - SATRONIC TF830B		
13A	C31-038N	PHOTOCELL LD (DANFOSS)		
13B	C31-039X	PHOTOCELL MZ 770 (SATRONIC)		

**NOTES**

- Categories: A - Recommended Short-Term Spares - Commissioning Spares (3 years)  
B - Recommended Long-Term Spares (5 years)
- When ordering spare parts it is essential to quote serial & specification number of burner
- Code numbers and types of electrical items are based on standard electrical supplies of 220-240 1phase 50Hz, or 380-440 3phase 50Hz

**SPARES AND COMPONENTS  
DIVISION**



NU-WAY LTD. P.O. Box 1, Vines Lane,  
Droitwich,  
Worcs., WR9 8NA, England  
Tel. 0905 794331 & 794242  
Fax. 0905 794017  
Telex 338551 Nuway G  
Registered in England No. 299044  
a subsidiary company of Wolseley plc.

**SPARE PARTS LIST**

BURNER MODEL **FOL/EOL 18-25-33**

Item	Code No.	Description	Category (see note)	Price
13C	C31-040C	PHOTOCELL LEAD FOR MZ770		
14A	C05-009R	IGNITOR - DANFOSS EBI 052F003088		
14B	C05-010D	IGNITOR - SATRONIC ZT900K		
15A	E03-029T	FILTER PP414		
15B	E03-011R	FILTER CROSLAND 18489		
16A	E03-034Q	ELEMENT PP414		
16B	E03-022L	ELEMENT CROSLAND 489		
17A	E05-027K	FLEX OIL PIPE - FOL		
17B	E05-061V	FLEX OIL PIPE - EOL		
18	G09-030N	MOUNTING GASKET		
19A	P24-209R	EXTERNAL OIL FEED PIPE - DANFOSS		
19B	P24-208Q	EXTERNAL OIL FEED PIPE - SUNTEC		
20A	H04-601C	NOZZLE - F/EOL 18, .40 x 80 DEG H		
20B	H04-604F	NOZZLE - F/EOL 25, (STD) .60 x 80 DEH H		
20C	HO4-602D	NOZZLE - F/EOL 25, (NI) .50 x 80 DEG H		
20D	H04-605G	NOZZLE - F/EOL 33, (STD) .65 x 80 DEG H		
20E	HO4-604F	NOZZLE - F/EOL 33, (NI) .60 x 80 DEG H		

**NOTES**

- Categories: A - Recommended Short-Term Spares - Commissioning Spares (3 years)  
B - Recommended Long-Term Spares (5 years)
- When ordering spare parts it is essential to quote serial & specification number of burner
- Code numbers and types of electrical items are based on standard electrical supplies of 220-240 1phase 50Hz, or 380-440 3phase 50Hz